
# **DEFAULT ROUTING**

#### What is Default Routing?

Default routing is a method where a network administrator configures a router to send all packets destined for unknown networks (networks not found in its routing table) to a specified next-hop address or outgoing interface. This is typically used in smaller networks or at network edges, where maintaining a complete routing table is unnecessary or impractical.

## **Default Routing Example Network Map Guide**

## **Network Topology & IP Setup**



Device	Interface	IP Address	Subnet Mask	<b>Default Gateway</b>
PC1	f0/0	10.0.0.1	255.0.0.0	10.0.0.100
PC2	f0/0	30.0.0.1	255.0.0.0	30.0.0.100
PC3	f0/0	50.0.0.1	255.0.0.0	50.0.0.100
Router0	f0/0	10.0.0.100	255.0.0.0	
Router0	s2/0	20.0.0.1	255.0.0.0	
Router1	f0/0	30.0.0.100	255.0.0.0	

Device	Interface	IP Address	Subnet Mask	Default Gateway
Router1	s2/0	20.0.0.2	255.0.0.0	
Router1	s3/0	30.0.0.1	255.0.0.0	
Router2	f0/0	50.0.0.100	255.0.0.0	
Router2	s3/0	30.0.0.2	255.0.0.0	- 10

Here is a step-by-step guide to performing default routing in a multi-router network, based on your network details and incorporating practical configuration and verification steps suitable for CCNA studies and Packet Tracer lab work.

#### **Configure Router Interfaces**

Assign correct IP addresses to each interface using interface and ip address commands in CLI.

For example on Router0:

interface f0/0

ip address 10.0.0.100 255.0.0.0

no shutdown

interface s2/0

ip address 20.0.0.1 255.0.0.0

no shutdown

Repeat similar assignments on Router1 and Router2 for their interfaces.

#### **Configure Default Routes**

On each router, add static default routes:

#### Router0

ip route 0.0.0.0 0.0.0.0 20.0.0.2

#### Router1

ip route 0.0.0.0 0.0.0.0 20.0.0.1

ip route 0.0.0.0 0.0.0.0 40.0.0.2

#### Router2

ip route 0.0.0.0 0.0.0.0 40.0.0.1

These commands direct any traffic with unknown destinations to a next-hop IP, ensuring packets leave the site.

## **Test Connectivity**

From each PC, use the ping command in the DOS/CLI prompt:

- o PC1: ping 30.0.0.1 (tests reachability to PC2)
- o PC2: ping 50.0.0.1 (tests reachability to PC3)
- o PC3: ping 10.0.0.1 (tests reachability to PC1)

If each configuration is correct, each ping should succeed, confirming default routing is operational.